
Chromebook Quick Guide

- Contact virtualtechsupport@ccsdli.org for any Chromebook issues
- To login, do not need to add @ccsdli.org just the username

Power button

Brightness up/down



Default browser is Chrome



To connect to a WiFi network, use drop down menu

To access settings, such as connecting to a WiFi network, and signing out of the device

Slots for power adaptor, HDMI, USB and headphone jack

