

SmartTV - Enable AirPlay

Enabling AirPlay On Your SmartTV

1. Turn on your TV and go to the "SmartCast" input.	
2. Go to the "Extras" option in the menu bar at the top of the screen.	
3. Go to the "SmartHome Settings" option.	
4. Go to the "Apple AirPlay and Homekit Settings" option.	
5. Select the "AirPlay Enabled" option and set this to "On".	

Note: If you still do not see your TVs name in the AirPlay list on your device, you may need to reboot your device.