


BrightLink

- Use the remote to turn the projector on.
- Tool bar should automatically appear on the side of the screen.

If not go to Start  Old programs —> Epson Programs —> Easy interactive tools

- You can also open up any existing SMART Notebook file to use with the BrightLink.
- You can convert word documents to a SMART Notebook file so students can write on worksheets using BrightLink

Click on File —Print —SMART Notebook doc. Writer —Print

The document will then be placed on a SMART Notebook page and can be saved and printed after the lesson is complete to be shared with students.

- To Right-click using the BrightLink pen- press and hold the pen down.
- The toolbox also has a variety of tools to use

